

What you need to install Fibo wall panels and Kitchen Board

WALL PANELS IN WET ROOM

Estimate that 1 pack (2 panels per pack) covers 1.2 meters of wall.

ACCESSORIES	AMOUNT
Fibo Screws - Installation screws w/bits 3,0 x 35 mm	30 screws/pack in 2400 mm height 35 screws/pack in 3020 mm height
Fibo Seal – sealant	1 tube covers max 3 panel packs
Fibo profiles - Base profiles - Internal corner profiles - External corner profiles - L-profiles	1 pcs (2400mm) covers 2 panel packs 1 pcs per internal corner 1 pcs per external corner Depending on design and potential finishing in the room
Fibo Wipes	1 package is sufficient for approximately 8 packs
Fibo Sealing Tools	1 package
Fibo Tapping Tool	1 piece is needed for a room with 2-part internal corner profiles
Fibo Grip	1 piece
Fibo Clean	1 pcs is sufficient for approximately 8 packs

KITCHEN BOARD

Estimate that 1 pack (2 Kitchen Boards per pack) covers 1.2 meters of wall.

ACCESSORIES	AMOUNT
Fibo Screws - Installation screws w/bits 3x20mm	5 screws per panel in 580 mm height
Fibo Seal – sealant	1 tub räcker till ca 13 pkt
Fibo profiles - Internal corner profiles - L-profiles	1 pcs per internal corner Depending on design and potential finishing in the room
Fibo Wipes	1 package is sufficient for approximately 12 packs
Fibo Sealing Tools – fogkloss	1 package
Fibo Clean	1 package is sufficient for approximately 12 packs

Tools needed for a smooth installation:

- Screwdriver
- Fine-toothed saw or circular saw
- Ruler and pencil
- Drill, hole saw, countersink, and jigsaw for making holes in the panels
- Spirit level

